U.S. Robotics®

N O T I C E

New DIP Switch Factory Settings

The factory settings of your modem's DIP switches have changed, as shown below. These new settings reflect the requirements of most applications and communications software packages. Disregard references in the documentation to the old factory settings of DIP switches 1, 6, and 9.

■ A black rectangle indicates the factory-set position of each DIP switch.



Slide-Type Switch—Used on
Courier HST Dual Standard
Courier HST
Courier V.32



Rocker-Type Switch—Used on
Courier 2400e
Courier 2400
Courier 1200

© Copyright 1989 by
U.S. Robotics, Inc.

1.015.327 Rev. A